



Prepare a clean area to lay out the parts for assembly. Assemble the parts in a location where they can be stood straight up into their final position.



Lay out the parts as they will be assembled.



Slide on the top C-Channels and fit plastic moulded corner in each end. Then slide the H-joiner up between the two sheets to be joined.



Gently tap the plastic corners into the H-Joiner to secure the sheets together.



Before fitting the bottom C-Channel, remove the tabs from the bottom of the lattice



Now fit the bottom C-Channel with the plastic moulded corners into each end and tap in lightly.

