

## Matrix lattice

There were three screens installed in the pergola pictured here. The two panel screens each took 20 minutes to assemble and secure into place. The three panel screen required a second person to help lift and position it, which took 25 minutes.

The flat mounting brackets were attached to the C-channels before assembly.

When the pergola was built, the top beam was positioned 2430 mm above the paving so that the lattice with the C-channel frames fitted without any cutting.

### Tips

If you have to cut the lattice to fit, make sure that you cut the same amount from both the lattice and the frame.

Make sure that the structure is square and able to support the weight of the lattice and the additional wind loads.

